

Cleaning the Spacer

1. In the case of regular use, the spacer should be cleaned once a week.
2. Disassemble the spacer and rinse the parts and mask in warm water with a little detergent.
3. Remove the cleaned parts from the water without rinsing them or drying them with a cloth. Let them air-dry overnight. The thin soapy film prevents the build up of electrostatic charge in the spacer.